



## SMART DIFFERENTIAL PRESSURE SENSORS

### with BACnet MS/TP & Modbus RTU communications


- No Long Term Drift
- No Temperature Shift
- Reduce on-site wiring and installation costs through monitoring over BACnet MS/TP or Modbus RTU networks

## SPECIFICATION


|                         |  |
|-------------------------|--|
| Power Supply:           | 24V AC/DC +/-15%   |
| Power Consumption:      | 100mA  |
| Selectable Ranges:      | TPDPT8/125: +/- 0-25, 0-50, 0-100, 0-125<br>TPDPT8/500: +/- 0-200, 0-300, 0-400, 0-500 |
| Communications:         | BACnet MS/TP or Modbus RTU (selectable)  |
| BACnet Baud Rates:      | 9600, 19200, 38400, 76800  |
| Modbus Baud Rates:      | 9600, 19200, 38400, 57600  |
| Outputs:                | 0-5V, 0-10V with 4-20mA  |
| Accuracy @ 25°C:        | 3.5% of reading + 0.15Pa   |
| Response Time:          | 5ms typical  |
| Burst Pressure:         | > 5bar   |
| Operating Temperature:  | -20 to 70°C  |
| Operating Humidity:     | 0-80% non-condensing   |
| Protection:             | IP65   |
| Connections:            | Screw terminals for 0.3mm² to 1.5mm² cable   |
| Recommended Cable type: | Screened Twisted Pair 0.75mm -1mm, screen earthed at controller end only               |
| Country of Origin:      | UK   |
| Product Code:           | TPDPT8/125-HA-COM<br>TPDPT8/500-HA-COM   |



## DIMENSIONS



## CONNECTIONS



## DIP SWITCH SETTINGS (PCB Base Board)

### Range Selection TPDPT8/125-HA-COM

| Range  | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 |
|--|-----|-----|-----|-----|-----|-----|
| 0-25Pa   | ON  | OFF | ON  | ON  | ON  | ON  |
| 0-50Pa   | ON  | OFF | ON  | OFF | ON  | ON  |
| 0-100Pa  | ON  | OFF | ON  | ON  | OFF | ON  |
| 0-125Pa  | ON  | OFF | ON  | OFF | OFF | ON  |
| For +/- Range Selection SW3 OFF<br>For 0-5V output Range Selection SW6 OFF |     |     |     |     |     |     |


### Range Selection TPDPT8/500-HA-COM

| Range  | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 |
|--|-----|-----|-----|-----|-----|-----|
| 0-200Pa  | ON  | OFF | ON  | ON  | ON  | ON  |
| 0-300Pa  | ON  | OFF | ON  | OFF | ON  | ON  |
| 0-400Pa  | ON  | OFF | ON  | ON  | OFF | ON  |
| 0-500Pa  | ON  | OFF | ON  | OFF | OFF | ON  |
| For +/- Range Selection SW3 OFF<br>For 0-5V output Range Selection SW6 OFF |     |     |     |     |     |     |

## BACNET / MODBUS SETTINGS

RS485 BACnet MS/TP or  
Modbus Communications  
COM/+VE/-VE

RS485 BACnet MS/TP or  
Modbus Communications  
LED Indication



### BACnet / Modbus Settings (1-5 Switch)

| Function                                    | Switch    | Operation  |
|---|-----------|--|
| End of Line Resistor                        | SW1       | OFF = RS485 Termination Resistor OUT / ON = RS485 Termination Resistor IN        |
| Communications selection                    | SW2       | OFF = BACnet MS/TP / ON = Modbus RTU   |
| Modbus Settings (only applicable if SW2 ON) | SW3       | OFF = Communication parameters from Modbus Register / ON = No parity 2 Stop Bits |
| Communications Baud Rate                    | SW4 & SW5 | See below  |

| Baud Rate | Communication    | SW4 | SW5 |
|-----------|------------------|-----|-----|
| 9600      | BACnet or Modbus | OFF | OFF |
| 19200     | BACnet or Modbus | ON  | OFF |
| 38400     | BACnet or Modbus | OFF | ON  |
| 76800     | BACnet           | ON  | ON  |
| 57600     | Modbus           | ON  | ON  |

### BACnet MAC / Modbus Slave Address settings

| Address Example | SW1 (1) | SW2 (2) | SW3 (4) | SW4 (8) | SW5 (16) | SW6 (32) | SW7 (64) | SW8 (128) |
|-----------------|---------|---------|---------|---------|----------|----------|----------|-----------|
| 1               | ON      | OFF     | OFF     | OFF     | OFF      | OFF      | OFF      | OFF       |
| 2               | OFF     | ON      | OFF     | OFF     | OFF      | OFF      | OFF      | OFF       |
| 3               | ON      | ON      | OFF     | OFF     | OFF      | OFF      | OFF      | OFF       |
| 4               | OFF     | OFF     | ON      | OFF     | OFF      | OFF      | OFF      | OFF       |
| 5               | ON      | OFF     | ON      | OFF     | OFF      | OFF      | OFF      | OFF       |
| 10              | OFF     | ON      | OFF     | ON      | OFF      | OFF      | OFF      | OFF       |
| 15              | ON      | ON      | ON      | ON      | OFF      | OFF      | OFF      | OFF       |
| 20              | OFF     | OFF     | ON      | OFF     | ON       | OFF      | OFF      | OFF       |
| 50              | OFF     | ON      | OFF     | OFF     | ON       | ON       | OFF      | OFF       |
| 100             | OFF     | OFF     | ON      | OFF     | OFF      | ON       | ON       | OFF       |
| 150             | OFF     | ON      | ON      | OFF     | ON       | OFF      | OFF      | ON        |
| 127             | ON      | ON      | ON      | ON      | ON       | ON       | ON       | OFF       |
| 254             | OFF     | ON      | ON      | ON      | ON       | ON       | ON       | ON        |

**Notes:** Switches use Binary to set device BACnet MAC address or Modbus Slave Address.  
 Value achieved by adding relevant switch values together. See examples above.  
 Switches all OFF or all ON are not valid settings for addressing.  
 Max MAC address for BACnet systems is 127.  
 Max Modbus Slave address is 254. Address 0 is not valid.  
 BACnet Device ID = Set MAC address + 151. It is recommended this is altered during commissioning via BACnet communications once device discoverable.  
 It is recommended to set the network addresses prior to powering up the device.

## BACnet points

| Object ID | Object Name           | Function   |
|-----------|-----------------------|--|
| DEVO      | Device Object         | ID, name, version etc.   |
| MSV0      | MAC                   | The current MAC address  |
| BV0       | Flash store           | Set True to store current values to flash memory so that they are not lost following a reboot.   |
| BV1       | Build Fail            | Is set to True if the primary configuration file fails to build. Unit will run on the secondary configuration until the unit is updated. |
| FILE1     | Config                | Backup and restore file.   |
| FILE2     | Firmware              | Backup and restore file.   |
| NC1       | NC1                   | Notification Class   |
| NC2       | NC2                   | Notification Class   |
| AV100     | Pressure              | Current pressure reading in Pascals.   |
| BV100     | Range Polarity        | 0= Positive only<br>1= +/- Range   |
| BV101     | Pressure Calibration  | Zero Calibration. Store current pressure reading as offset.  |
| MSV100    | Sensor Type           | TPDP8 Model Type (125Pa, 500Pa, etc.)  |
| MSV101    | Sensor Pressure Range | Maximum pressure value (e.g. 125/-125)   |

## Modbus Registers

| Register No. | Register Type  | Parameter       | Units  |
|--------------|----------------|-----------------|--|
| 1            | Input Register | Sensor Mode     | 1: Pressure  |
| 2            | Input Register | Pressure        | Pascals  |
| 5            | Input Register | Sensor Type     | 1: TPDP8/125<br>2: TPDP8/500   |
| 6            | Input Register | Sensor Polarity | 0: +/- Range<br>1: Positive only   |
| 7            | Input Register | Pressure Range  | Pascals:<br>TPDP8/125: 1: 125; 2: 100; 3: 50; 4: 25;<br>TPDP8/500: 5: 500; 6: 400; 7: 300; 8: 200<br>Note: 0=N/A |

**Note 1: All registers are unsigned expect Register no. 2**

## Writable Coils

| Coil No. | Parameter          | Action   |
|----------|--------------------|--|
| 1        | Offset Calibration | Take the current pressure and store it as offset calibration |

### Default factory settings:

- Baud rate: **38400** bps
- MAC: 50 (Modbus ID)
- Stop Bits: **2**

### Sensor Notes

1. Solvents in the air derived from sources such as paints, cleaning products and adhesives can have a detrimental impact on the sensor cell. All sensors should therefore be installed after the space has been decorated and any flooring fitted. The sensors should also be kept away from adhesives and should the housing require cleaning, a dry non-solvent based product must be used. Do not spray any liquid or cleaning products directly onto the ventilated housing. Exposing the sensor to such solvents or moisture will invalidate the product warranty. Do not blow directly on to the CO2 cell within the sensor, this can damage the cell membrane and could cause incorrect readings.

2. Disposal: At the end of their useful life the packaging and product should be disposed of in accordance with the below depending on the country of your disposal:

- WEEE Directive 2012/19/EU and its amendments (EU). • The Waste Electrical and Electronic Equipment Regulations 2013 (as amended).
- Do not dispose of with normal household waste. Do not burn.